

SMARTRACING™

PRODUCTS

*A Company Developing Smart Racing
Products Through Engineering*

996 Control Arm Pin Update

- 443110 Fabcar Control Arm Pin
- 443120 Fabcar Control Arm Monoball
- 443140 Fabcar Control Arm Circlip
- 443141 Fabcar Control Arm Nut
- 443150 Boot (Optional)

Installation 996 Control Arm Pin Update



Assembly

1. Install Monoball into Arm.
2. Install Circlip.
3. Install Pin through Monoball.
4. Install M12 nut.
5. Install (optional) rubber boot.
6. Install arm into car
7. Titan M14 nut to 133 ft/lbs using red Loctite.
8. Titan M12 nut to 83 ft/lbs using red Loctite.

Questions or comments please call 408.369.9997 or FAX 408.369.9915
www.smartracingproducts.com