

SMARTRACING™

PRODUCTS

*A Company Developing Smart Racing
Products Through Engineering*

AJ Front Brake Duct
691062/63-911 and 691072/73-930

Instructions AJ Front Brake Duct



1. Jack up front of vehicle and place on jack stands
2. Remove front wheels.
3. Remove front brake calipers: do not hang the caliper from the brake line, support it with wire.
4. Remove wheel bearing dust cover and spindle nut.
5. Remove rotor/hub assembly.
6. Remove original dust shield from strut.
7. Install air duct over the spindle, attach using the original hardware.
8. Reinstall rotor/hub and spindle nut, tighten to factory specs.
9. Reinstall calipers. Pump brake pedal a few times to reposition brake pads, bleed brakes if necessary.
10. Install front wheels, torque wheel nuts to factory specs.
13. Lower vehicle, installation is complete.



If you have a front valance that has air inlet holes,
please use our A-arm air manifolds, part #691030.

Questions or comments please call 408.369.9997 or FAX 408.369.9741
www.smartracingproducts.com